

Work Order ID 57507

Wednesday, April 07, 2010 3:21:46 PM

Page 1

*Scrap*

Item ID: D212-664-101

Revision ID:

Item Name: Crosstube Fwd

Start Date: 4/7/2010 Start Qty: 1.00

Required Date: 4/7/2010 Req'd Qty: 1.00

Reference: Return 2010 / RA110014

Accept



Setup Start

Stop

Cust Item ID:

Customer:

Approvals:

Process Plan:

Date:

Tooling:

Date:

QC:

Date: 10/4/06

SPC (Y/N):

Date:

Run Start

Stop

Sequence ID/
Work Center IDOperation
DescriptionSet Up/
Run HoursDraw
NumberDraw
Rev.Plan
CodeAccept
QtyReject
QtyReject
NumberInsp.
Stamp

Draw Nbr

Revision Nbr

D212-664-141

Rev D

100

0.00



QC

Quality Control

Memo

0.00

Tube was inspected in house.
See NCR10-023 for more details.. Tube was NDT'd & no stress was apparent.
Tube is scrap.

110

0.00



QC

Quality Control

QC21- Final Inspection - Work Order Release

Memo

0.00

1 *100406**10/04/12*
MF
10-4-9

10-107

10-107

10-107

10-107

10-107

10-107

10-107

10-107

10-107

10-107